


ASSEMBLY INSTRUCTIONS

First of all, correctly spread out all of the pieces you are about to put together.

Step 1: Fitting SIDE RAILS

Place the headboard against the wall to perform this step.

- Ensure **the metal brackets** on the headboard and footboard are **square** to the side rail brackets prior to putting each side rail in photo A and B.
(note: do not lock one side of a side rail in too firmly).
Then, push down with your foot gently to complete (photo C).



Step 2: Fitting THE CENTER RAIL



- Extend the centre rail and fit to the headboard and footboard.



- Fit and tighten **the extension rail lock bolt**.



- Remove the **centre leg extension** from its packaging, and slide it onto the **centre leg**.
- Fit and tighten the extension section by inserting the nut into **the first hole** (from the ground), and securing it with the bolt.




Step 3: Fitting THE CENTER LEG'S FOOT

★ This is the most important step to have a strong bed.

- Unscrew the rubber foot under the centre rail leg **until it touches the ground.**



- Turn the nut clockwise to bring it up to the end of the extension leg, **then tighten it.**



Step 4: Fitting SLATS

When fitting the slats into the side rails, **ensure they fit firmly into their positions**



The assembly is now completed. The mattress can go on top of the slats.

- Every few months, turn the mattress over to the other side, and
- Readjust the slats to ensure they didn't move out of their slots, and
- Re-screw the nut of the center leg to have it firm complete.